



\* Flags and sticky-notes not included.




MADE IN CHINA with foreign materials

## Installation of the Kornerkeeper

**Please read all instructions before attempting to install.**

1. Unplug the monitor from both the computer and the power.
2. Clean the face of the monitor as per manufacturer recommendation where the *Kornerkeeper* attaches. After proper cleaning, use the enclosed alcohol swab to wipe the areas of the frame around the monitor screen where the "fastener tab" will adhere. **Note: Wipe ONLY the frame around the screen, alcohol may damage some clear plastics, LCD screens, antiglare or polarized screens.** Then use the alcohol swab to wipe down the tape blocks on the back of the *Kornerkeeper* at locations "A", "B", & "C" (**See illustration 1**). Allow the areas wiped down with the alcohol swab to dry completely before continuing.
3. Turn the *Kornerkeeper* over so the back side is facing you. Take the included three 1-inch X ¾-inch mated "fastener tabs", peel the liner off one side (exposing the adhesive) and adhere them inside the 3 engraved rectangles indicated in **illustration 1** at locations "A", "B", & "C". **Note: Keep the fastener tabs slightly set in from the edge so they will be less visible when viewing from the front.**
4. Decide where you want your *Kornerkeeper* attached by holding it up to your monitor (it can be located on the upper left or right side of your monitor). Remove the remaining liners from the "fastener tabs", exposing the other side of the adhesive, hold the *Kornerkeeper* in both hands, and carefully locate the *Kornerkeeper* aligning it along the edges of your monitor screen. Hold it close to the monitor without touching the adhesive. Once located, press into the desired location. \*\*
5. Press firmly against the frame where your "fastener tabs" are located, to ensure a good bond.
6. After approximately 10 minutes, remove the *Kornerkeeper* from your monitor by bending it slightly and pulling. Make sure that the "fastener tab" has separated and is firmly attached to both the monitor and the *Kornerkeeper*. Leave the Monitor and the *Kornerkeeper* separated for 24 hours to allow the adhesive to reach full strength before reattaching and using the *Kornerkeeper*.

*Note: Some of the large older CRT monitors have deep horizontal and vertical curves that prevent the adhesive or "fastener tabs" from staying connected. For these few circumstances where the monitor's edges are not even close to flat, snap on the provided "riser block" between the "fastener tabs" you previously adhered at location "B" to hold the inside corner of the *Kornerkeeper* slightly farther away from the monitor to relieve the stress on the *Kornerkeeper*, allowing it to stay connected. (See illustration 2)*



\*\* If placement of the *Kornerkeeper* against your monitor face is slightly misaligned you may quickly pull off the "fastener tabs" and re-adhere. The adhesive bond is not as strong in the first seconds of adhering but will reach 70% of its strength in the first hour of adhesion.

### **Installation of Photographs**

1. Remove a Snap-in Frame from a pocket by carefully lifting from one of the sides without a hold down nib, and carefully sliding it out. **Note: Lifting from a side with a hold down nib will damage the nib.**
2. Align the Snap-in frame over your selected photo or image. Carefully trace around the frame with an appropriate marking pen.
3. Cut out the image with your scissors staying slightly inside the lines that you drew, and place into a pocket on the Kornerkeeper. **Make sure that your image is slightly smaller than the pocket. It must lay flat. If it's touching the sides of the pocket, trim off the edges that touch the sides. Note: It is better if the photo is a little loose in the pocket.**
4. Insert the Snap-in Frame into the pocket to hold it into place.
5. Repeat these steps for all of the pockets.

### **Care Instructions**

Periodically dust your Kornerkeeper to maintain its attractive appearance. To clean the Kornerkeeper, separate it from the monitor and remove any photos and components. Carefully wipe with warm water (no detergents) and a non-abrasive cloth. Make sure your Kornerkeeper is completely dry before re-assembly.

### **Installing a Component Accessory in the Kornerkeeper™**

A separately purchased Component Accessory may be installed in different ways depending upon the component purchased. You should follow the installation that comes with each component.

***To learn about other exciting pieces in the Kornerkeeper™ line or about the new add-on components, visit us at [www.kornerkeeper.com](http://www.kornerkeeper.com)***

### **Customize**


You can unleash your creativity and customize your Kornerkeeper in your own way. You can make your Kornerkeeper more functional by replacing some of the photos with separately purchased super sticky notes, flags, etc. and adhering them into the pockets. For the scrapbooker or craftier consumer, you can literally decorate your Kornerkeeper as if you were decorating a page in your scrapbook.

***For frequently asked questions, new products, add on components, and other useful information, go to: [www.kornerkeeper.com](http://www.kornerkeeper.com)***

***Do not return the Kornerkeeper to retailer.***

***If you are missing parts or having a problem that is not resolved on the FAQ page on the web site, please contact us for help.***

**Contact Us:** Web site: [www.kornerkeeper.com](http://www.kornerkeeper.com), email: [email@kornerkeeper.com](mailto:email@kornerkeeper.com)

**GrafixWrap, Inc.**   
6899 Peachtree Industrial Blvd., Suite E, Norcross, Georgia 30092